


CONTROL SYSTEM (L3 Turbo)

0140-3d

108



0140-310 INJECTOR DRIVER MODULE(SHORT CORD) <div> </div>		0140-311 FUEL INJECTOR NO.1(INJ) <div> </div>	0140-312 FUEL INJECTOR NO.2(INJ) <div> </div>	0140-313 FUEL INJECTOR NO.3(INJ) <div> </div>
0140-314 FUEL INJECTOR NO.4(INJ) <div> </div>	0140-315 FUEL INJECTOR RELAY(F) <div> </div>			

HARNESS SYMBOL :  (F)  (E)  (D)  (R)

