



INPUTS

**Do not connect shield
at sensor end**


Crank or
Distributor
Trigger
(See
(Trigger
(Drawings)




Injector
Timing
(Hall
(Sensor
(Optional)




Manifold
Pressure




Exhaust
Manifold
Pressure




Throttle
Position



Air Temp



Engine
Temp




Air Fuel
Sensor or
Meter
(Optional)



Cut Link
for Magnetic
Trigger Sensor

21 Hall A
22 Hall B




Looking into ECU connector


OUTPUTS

ECU
Configurable
HALL/ Magnetic


Injector
Group A




Injector
Group B




Auxiliary
Control
Valve



Fuel Pump
Relay




Ignition
Module
Drive



12V

12V



+
12 Volt
Battery

GND

GND

5 Black

6 Black

Earth at Engine
Block

MoTeC

Title **2 GROUP CEM REV E**

Date 31/05/2000

Drawn ST

App

Products ECU

Sheet No

1 of 1

Drawing No

ECU