



NOTE
For Multi coil use refer to drawing numbers:
M4/M8- M02, M03 & M04

Setup	ign	1
	COIL	3
	dELL	Note 1

NOTE 1
The setup parameter dELL is dependant on the coil.
Refer to the information for the particular coil.

Typically a value of 3.0 is suitable for normal coils.
For small coil on plugs a value of 1.8 is typical.

Important: Using an incorrect value may cause overheating
of the ignition module or a weak spark.